

# Roon

Roon 가 . Control, Output, Core . Roon .

## Roon Ready

Roon Ready Roon Server, Roon Remote . Roon Ready  
RoonBridge , . hqplayer\_naa





Roon Ready 'Active' . Roon Ready가





- **Audio device config:** USB DAC
- **Volume mode:** Fixed, Software, Device Controls
- **DSD mode:** DSD NONE, NATIVE, DOP, DCS, NATIVE/DOP, NATIVE/DCS
- **DSD rate:** DSD x64, x128, x256
- **Buffer duration:** 가
- **Resync delay:** 0.1 ~ 0.5 0.01

## Roon Ready

Roon Ready 'Active' Roon Desktop Setting > Audio Roon  
Ready SMS-200



## Audio Zone



## Roon Server


Roon Server   Roon Core   Roon Output

Roon Remote


. [Roonlabs](https://www.roonlabs.com)

# Roon Server



Roon Server



Roon Server 가 (Active) Roon Desktop Core SMS-1000SQ Core



Core



### Audio Zone



: 2017/01/24 22:34

From:  
<https://www.wiki.sotm-audio.com/> - **SOTM docs**

Permanent link:  
<https://www.wiki.sotm-audio.com/doku.php?id=ko:roon&rev=1485315253>

Last update: **2017/01/24 22:34**

