


Roon

Roon . Control, Output, Core 가 Roon .

Roon Ready

Roon Ready Roon Server, Roon Remote . Roon Ready
RoonBridge , . hqplayer_uaa

Roon Ready config



- **Audio device config:** USB DAC
- **Volume mode:** Fixed, Software, Device Controls
- **DSD mode:** DSD NONE, NATIVE, DOP, DCS, NATIVE/DOP, NATIVE/DCS
- **DSD rate:** DSD x64, x128, x256
- **Buffer duration:** 가

- Resync delay: 0.1 ~ 0.5 0.01

Roon Ready


Roon Ready
Ready

'Active'
SMS-200

. Roon Desktop


Setting > Audio

Roon





Audio Zone






Roon Server


Roon Server Roon Core Roon Output Roon Remote [Roonlabs](#)

Roon Server


[Roon Server](#)




[Roon Server](#) 가 (Active) Roon Desktop Core SMS-1000SQ Core



Core





Audio Zone



: 2017/01/25 00:23

From:
<https://www.wiki.sotm-audio.com/> - **SOTM docs**

Permanent link:
<https://www.wiki.sotm-audio.com/doku.php?id=ko:roon&rev=1485321800>

Last update: **2017/01/25 00:23**

